






TRANSMETTEURS DE PRESSION



Version	Réf.	Particularités	Échelle (bar)	Alerte (bar)	Filetage		
	360081029004	Retour par la masse	5		1/8 - 27		
	360081029001		5		10 x 100		
	360081029010		10		10 x 100		
	360081029033		10		14 x 150		
	360081029012		10		1/8 - 27		
	360081032011	Isolé de la masse	2		12 x 150		
	360081032025		2		1/8 - 27		
	360081032002		5		10 x 100		
	360081032013		5		18 x 150		
	360081032001		5		1/8 - 27		
	360081032003		10		10 x 100		
	360081032006		10		14 x 150		
	360081032014		10		1/8 - 27		
	360081038001		25		14 x 150		
	360081038003		25		1/8 - 27		
	360081038002		25		3/8 - 18		
	360081038005		28		18 x 150		
			360081030002	Retour par la masse et borne d'alerte	5	0,5	10 x 100
			360081030028		5	0,5	14 x 150
360081030049		5	0,4		1/8 - 27		
360081030004		5	0,7		10 x 100		
360081030010		5	1,4		1/8 - 27		
360081030009		10	0,5		10 x 100		
360081030022		10	0,5		12 x 150		
360081030032		10	0,5		14 x 150		
360081030052		10	0,5		1/8 - 27		
360081030039		10	0,75		10 x 100		
360081030015		10	0,8		1/8 - 27		
360081030017		10	0,9		10 x 100		
360081030041		10	2		10 x 100		
	362081001001	Isolé de la masse pour branchement de 2 indicateurs sur un transmetteur	5	Pour 2 indicateurs	1/8 - 27		
	362081001002		10	Pour 2 indicateurs	1/8 - 27		
	362081002001		25	Pour 2 indicateurs	1/8 - 27		
	362081002002		25	Pour 2 indicateurs	3/8 - 18		
	360081039002	Isolé de la masse et borne d'alerte	5	0,8	1/8 - 27		
	360081039003		10	0,8	1/8 - 27		

