Teck Step 1 cleaner Nautic Clean 17 - 220 l



Réf : **NC17220**

The teak cleaner phase 1 T17 proves to be highly effective for teak restoration and maintenance. Thanks to its exceptional ability to deeply penetrate and wet the surface, it successfully dislodges and efficiently removes even the most stubborn impurities, such as black dust, dried mold, and oily stains.

Classic delivery

Public price TTC
N.C.

CARACTERISTICS

TECK STEP 1 CLEANER NAUTIC CLEAN 17 - 220 L
Réf. **NC17220**

- Model : Nautic Clean 17
- Weight : 239 kg

Dangerous material : non
Weight : 239,00 kg.
Catalog page : 150

SPECIFICATION

To achieve a flawless restoration, we have developed a two-component system featuring the Teak Cleaner Phase 2 T18, a degreasing agent specially designed for teak.

Advantages:

- Very easy to use.
- Formulated specifically for teak maintenance.
- No harmful effects on joints (lab-tested).
- No harmful effects on stainless steel (lab-tested).
- Contains plant-based surfactants.
- Free from phosphates, NTA, or chlorine.
- Perfect teak restoration with an impeccable finish thanks to TEAK STEP 2 Degreaser.

Usage and Maintenance:

Dosage: 1 part TEAK STEP 1 to 3 parts water.

Spray or spread the solution on the surface to be treated using a soft brush, scrub in the direction of the grain, and leave it for 10 minutes. Do not rinse.Then, apply TEAK STEP 2 degreaser by spreading it with a clean brush. You will notice that the teak gradually regains its natural color as you apply TEAK STEP 2.

Rinse gently with a deck brush to preserve the teak fibers.